


ROJO PARTFILL

PRODUCT INFO



Partfill



20 L / MIN

Description



Rojo Partfill is a low flow valve intended for use in rain water harvesting tanks. The purpose of the float valve is to automatically maintain a low level of water in the tank during periods of no or low rainfall. This allows services fed by the tank to continue while leaving capacity in the tank for refilling by the next rain.

Applications

Maintaining water levels in:

- Rain water harvesting tanks
- Water cisterns
- Irrigation and process applications.

Flow Graph



Outline of Operation

- The valve is installed through the side wall of a storage tank. It should be mounted above the overflow level of the tank to prevent backflow.
- As the tank empties the weighted float travels down the cord and sits on the bottom stop to activate the valve.
- The valve will run until the weighted float lifts clear of the bottom stop.
- The float will then rise as rainwater fills the tank and falls as the tank water is used.
- The valve will only function at times when rain fall is insufficient to maintain a water level in the tank above the bottom stop.
- The use of a flow restrictor before the valve will not cause the valve to malfunction.

Features

- Ideal for use with all makes and models of rain water harvesting tanks
- Compatible with trickle flow restrictors
- Compact
- Constructed from non corroding materials
- Built in non return valve
- Valve can be locked in off position using the lock off switch

Available Inlet Sizes


15mm (1/2")
20mm (3/4")

All supplied with long tail thread with back nut.

Pressure Range

0 – 10 Bar (0 -150 psi)

Typical Installation



Note: Keep overflow, rain water inlet and outlet to pressure pump as far away from the float valve as possible.




ROJO PARTFILL

DIMENSIONS & MATERIALS



Partfill

20 L / MIN



Part	Material	Part	Material
Valve Body	ABS	Float	HDPE
Tail & Nut Arm		Springs	304 Stainless Steel
Extension Arms	Glass Filled Nylon	Bolts	
Internal Grey Mouldings		Nuts	
		O'Rings	Nitrile
Yellow Valve Parts	Acetal	Float Cord	Polyester
Filter			

Maximum Operating Temperature 60°C, 140°F

ROJO PARTFILL

PARTS IDENTIFICATION SHEET





Partfill

WaterMark
AS 1910
Lic 21606
SAI Global

CS®
US
NSF/ANSI/CAN 61

20 L / MIN



CODE	DESCRIPTION
1 RJPP1	Float Assembly
2 RJPP2	Body Assembly
3 RJPP3	Inner Cartridge Assembly (PF)
4 RJP415	15mm (1/2") Tail Assembly
RJP420	20mm (3/4") Tail Assembly
RJP420E	20mm (3/4") NPT Tail Assembly

